

CRJ-700/900/1000 Normal Procedures Checklists

Checklists might slightly vary between carriers and CRJ models

SAFETY CHECKS

Parking Brake ----- SET
Landing Gear ----- DOWN
Flight Spoilers ----- 0
Nose Wheel Steering ----- OFF
Throttle ----- SHUT OFF POSITION
Flaps ----- 0
WX Radar ----- OFF
ADG Manual Release ----- Stowed
Emergency Flaps ----- NORMAL

COCKPIT PREPARATION

Battery ----- ON
Fire Detect (first daily flight) – TEST
AC Switch (if GPU available) -- ON
APU and Main Battery ----- Check if > 22V
APU PWR/FUEL ----- ON
APU Start/Stop ----- START
GEN Switches ----- AUTO
NAV Lights ----- ON
LOGO Lights ----- ON
FMS ----- PROGRAMMED
Packs L & R ----- ON
Recirc Fan ----- ON
Windshield Heating LH & RH ----- LOW
ELT ----- ARM/RESET
Stall Warning (first daily flight) --- TEST
Anti-Skid (first daily flight) ----- TEST
MLG BAY OVHT TEST (first daily flight) – TEST
Anti-Skid ----- ARM

DeltaWing Simulations © 2021/23

FOR FLIGHT SIM USE ONLY – NOT TO BE USED IN REAL LIFE OPERATIONS!



Engine Sync ----- N1
Spoilers GND Lift Dump ----- AUTO
Thrust Reverser LH & RH ----- ARMED
Flaps -----TAKEOFF
TCAS ----- TEST
Stab Trim & Mach Trim ----- ON
Yaw Damper ----- ON

BEFORE ENGINE START

Ground Equipment ----- REMOVED
Wheel Chocks ----- REMOVED
Doors ----- CLOSED
Passenger Signs ----- ON
LDG Elevation ----- SET
Barometric Pressure ----- SET
Autopilot, Altitude, RWY Heading ---- SET
V-Speeds ----- SET
Transponder ----- SET
Trims ----- VERIFIED FOR TAKEOFF
Boost Pumps L and R ----- ON
Hydraulic Pumps ----- AUTO/ON

ENGINE START

Beacon ----- ON
Engine Left ----- START
When N2=20%, Thrust Lever ----- Position from SHUT OFF to IDLE
Engine Right ----- START
When N2=20%, Thrust Lever ----- Position from SHUT OFF to IDLE

BEFORE TAXI

Probes LH and RH ----- ON
Anti-Ice ----- AS REQUIRED
Taxi Lights ----- ON
APU Start/Stop ----- STOP

DeltaWing Simulations © 2021/23

FOR FLIGHT SIM USE ONLY – NOT TO BE USED IN REAL LIFE OPERATIONS!



APU PWR/FUEL ----- OFF
N/W STRG (Nose Wheel Steering) ----- ARMED

BEFORE TAKE-OFF

Landing Lights ----- ON
Strobe Lights ----- ON
Beacon Lights ----- ON
Taxi Lights ----- ON
Fuel XFLOW ----- MAN
Transponder ----- ON
TCAS ----- AS REQUIRED
Terrain Display ----- AS REQUIRED
CAS ----- CHECKED/CLEARED

AFTER TAKE-OFF

Landing Gear ----- UP
Flaps ----- RETRACTED
Fuel XFLOW ----- AUTO
Thrust Reversers L and R ----- OFF
Lights ----- AS REQUIRED
Passenger Signs ----- AS REQUIRED

DESCENT

Landing Elevation ----- SET
Fuel ----- CHECK
TCAS ----- AS REQUIRED
Terrain Display ----- AS REQUIRED
CAS ----- CHECKED/CLEARED
Landing Data ----- SET

APPROACH

Barometric Pressure ----- SET
Lights ----- SET
Passenger Signs ----- AS REQUIRED

DeltaWing Simulations © 2021/23

FOR FLIGHT SIM USE ONLY – NOT TO BE USED IN REAL LIFE OPERATIONS!



BEFORE LANDING

Passenger Signs ----- ON
Thrust Reversers L and R ----- ARMED
Landing Gear ----- DOWN
Flaps ----- SET

AFTER LANDING

Spoilers ----- RETRACTED
APU PWR/FUEL ----- ON
APU Start/Stop ----- START
Transponder ----- STBY
Terrain Display ----- OFF
Flaps ----- RETRACTED
Landing Lights ----- OFF
Strobe Lights ----- OFF
Taxi Lights ----- ON
Probes LH and RH ----- ON

SHUTDOWN

Parking Brake ----- SET
Throttles ----- SHUT OFF POSITION
Anti-Ice ----- OFF
Passenger Signs ----- OFF
Boost Pumps L and R ----- OFF
Hydraulic Pumps ----- OFF
Beacon Lights ----- OFF
N/W STRG (Nose Wheel Steering) ---- OFF
ELT ----- OFF
External Lights ----- OFF
APU Start/Stop ----- STOP
APU PWR/FUEL ----- OFF
Internal Lights ----- OFF
Battery ----- OFF

DeltaWing Simulations © 2021/23

**FOR FLIGHT SIM USE ONLY – NOT TO BE USED IN REAL LIFE
OPERATIONS!**

